



# SMOK

## **For Write NEW KM**

1. Open ECU.
  2. Conect it as on pic.1 (Boot Mode). (pic.1 aviable in topic Read Component Security )
  3. Select PCR2.1 from Menu next from panel 'Flasher' push Button 'Boot mode EEp'
  4. Read KM -we can check actual Value
  5. Write KM
  6. Close ECU and put to the car
- thas all :)